



An Alexander's U-Rent Company  
1127 Andover Park W., Bldg D  
Tukwila, WA 98188  
(206) 282-1987 Phone (206) 283-4545 Fax

**CAMTHERM ELECTRIC HOT BOX  
INSTRUCTIONS FOR USE**

**For maximum holding performance and to ensure safe food holding temperatures, pre-heat cabinet at least 45 minutes before loading with hot food.**

**OPERATION:**

- Plug in unit
- Adjust racks as needed. NOTE: If you remove racks, please be sure to keep them in a safe place. You will be charged a replacement fee for missing racks.
- Flip power switch on back of unit to on.
- Set temperature dial to desired setting (minimum 150°F - maximum 165°F).
- Allow 45 minutes for unit to preheat to 165° before loading food.

**CAUTION: Never use any type of canned/portable cooking fuel inside a Cambro transporter.**

- Load food when thermostat on outside of the door reads 165°F.

**CAUTION: Always cool metal pans or sheet pans to 250°F before placing into a transporter or on any transporter surface. Best results will be achieved by loading food pans between 180°F to 190°F**

- Unit requires a 4 min recover time to return to 165°F after door is open.
- Before transporting or relocating cabinet, first ensure door is completely shut and latched.
- To transport, turn off power then unplug and wrap cord around holder.
- When unit is at 165°F, transportation time is 8 hours i.e.: if left unopened, unit can be unplugged this amount of time before the temperature will drop below 140°F.
- When placed in new location, plug in unit and flip power switch back on.
- To vent steam: gently pull out the black vent button on the door; it will only move a small amount.

**AFTER USE:**

- Turn off power, unplug cord and wrap back around holder.
- Remove all food pans (pans rented from Alexander's with the unit must be rinsed prior to return).
- Wipe up any food spilled inside the unit.
- Replace any racks which may have been removed.